


HT-5000P

Dielectric Withstand Tester

0-5000 Volts AC Output

0-6000 Volts DC Output

Instruction Manual



COMPLIANCE WEST USA

The blue box that tests. And tests.

Dear Customer:

Congratulations! Compliance West USA is proud to present you with your Dielectric Withstand Tester. Your instrument features a groundbreaking logic-controlled circuit design and ergonomic front panel and represents the latest in high voltage production line testing.

To fully appreciate all the features of your new meter, we suggest that you take a few moments to review this manual. If need arises, please don't hesitate to call us.

Thank you for your trust and confidence.

Table of Contents

An Introduction to Dielectric Withstand Testing with the HT-5000P	1
Safety Precautions	1
Test Personnel	1
Testing Area	1
Safety Techniques	2
Using the HT-5000P Dielectric Withstand Tester	2
Leakage Test	2
Sporadic Leakage Current Failures	3
Chronic Leakage Current Failures	3
High Voltage Dielectric Withstand Test.....	3
High Voltage Dielectric Withstand Test Failures.....	4
High Voltage Discharge	4
Introduction and Specifications	5
Specifications	6
Table 1. HT-5000P V2 Specifications	6
Operation.....	7
Setting up your Tester.....	7
AC Line Voltage Requirements.....	7
Fuse Replacement	7
Front and Rear Panel Features	8
Figure 1. Controls, Indicators, Connectors - Model HT-5000P Front Panel.....	8
Table 2. Controls, Indicators, Connectors - Model HT-5000P Front Panel	8
Figure 2. Controls, Indicators, Connectors - Model HT-5000P Rear Panel.....	9
Table 3. Controls, Indicators, Connectors - Model HT-5000P Rear Panel.....	9
Factory Settings	10
Display of Leakage Limit and Duration settings.....	10
Leakage Current Level Adjustment.....	10
High Voltage Ramp Time Adjustment.....	10
Adjustment of the High Voltage Level.....	11
Adjustment of the High Voltage Test Time	11
Setting the Rear Panel Switches	12
Table 4. Rear Panel Switch Truth Table.....	12
Table 5. Rear Panel Switch Condition Table.....	12
Operating Techniques.....	13
Operational Test.....	13
Testing	14
Test Procedure Example:	14
Figure 3. Connection example	15
Test results.....	15
Technical Assistance	16
Maintenance and Calibration	17
Introduction	17
Service Information	17
General Maintenance.....	17
Interior Access	17
Calibration Access	18
Cleaning	18
Calibration Procedure	18
Calibration and Software Version Information	18
Voltage Calibration Adjustment.....	19
Figure 4. Connection for Voltage Adjustment	19
Current Calibration Adjustment.....	20
Figure 5. Connection for Current Adjustment	20

Section 1

An Introduction to Dielectric Withstand Testing with the HT-5000P

The dielectric withstand test is a production line test which is recognized by safety agencies worldwide as a valid criterion of safe assembly of end-use equipment. The test ensures that the primary circuit power was properly wired and connected for safe operation. It also applies to a high-voltage potential between power and ground conductors to make sure that no unintentional leakage or arcing paths exist between power and ground. The test consists of a leakage current check and a high voltage check. It is non-destructive to the equipment under test and can be accomplished in a short time.

Safety Precautions

The dielectric withstand test generates voltages of up to 5000 volts AC or 6000 volts DC at potentially lethal current levels. Currents of as little as 5 mA at 120 volts can cause death, and the HT-5000P can generate up to 10 mA AC and 5000 volts, and 5 mA DC at up to 6000 volts. The HT-5000P has been designed to minimize exposure to high voltages. However, the potential for serious injury or death exists and personnel should be aware when they conduct this test.

Test Personnel

Personnel require special training to conduct the dielectric withstand test. They should understand electrical fundamentals clearly and be aware that high voltage is adept and creative at completing a path to ground. Instructions should include a warning against any metal jewelry. Operators should not allow others in the testing area, especially when tests are being conducted. Organization is to be stressed. The operator should keep the area free of unused leads and equipment.

Testing Area

The area used for conducting the dielectric withstand test should be as remote as possible from normal production line activities. Only personnel conducting the test should be allowed in the area, and it should be taped or roped off to preclude casual entry by other employees. In addition, the area should be marked "WARNING - HIGH VOLTAGE TESTING" or the equivalent to warning others of the nature of the testing taking place.

The bench being used should be non-conductive, and any exposed metal parts should be tied together and grounded. If a conductive surface must be used, it should be grounded.

Because of sparking during a dielectric test failure, it is not safe to conduct dielectric withstand tests in combustible atmospheres.

It is imperative that a good ground be provided to the HT-5000P. Before connecting the HT-5000P, ensure that a low-resistance ground is provided by the building wiring. If the HT-5000P is used on a high-resistance grounding circuit, dangerous high voltages may be present to the operator. In addition, the power to the Testing Area should be provided with an easily reached shutoff switch which can be actuated by personnel outside the Area if needed.

Safety Techniques

The high voltage circuit of the HT-5000P can be shut off at any time by pressing the **RESET** button. The HT-5000P has been provided with a reset switch to provide an unarmed "Standby" setting when it is energized, but idle. When the red **RESET** button is lit the tester will not provide high voltage until the **RESET** button and the yellow **TEST** button have been pressed in order. To prevent inadvertent operation, the operator should be instructed not to press the **RESET** button until the test is ready.

It is imperative that the operator make sure the test return lead is properly connected to the equipment being tested. If the lead is not properly connected, a dielectric withstand test failure may energize exposed dead metal of the equipment being tested. Additionally, the HT-5000P may not recognize the failure. The test will continue for its normal length of time, and the HT-5000P may show a "PASS".

The HT-5000P has been designed for one-touch operation with the right hand. If possible, it should be set up to the left and in front of the equipment under test. The equipment under test should be connected to the HT-5000P and then left alone by the operator. After the operator is clear of the tester and the equipment under the test, he should press the **RESET** Button, then the **TEST** Button, with his right hand. This will allow the greatest separation between the operator and the test being conducted.

The HT-5000P is designed to bleed the high voltage away after the test has concluded. To ensure that any voltage present in the equipment being tested has been completely bled away, the operator should not unplug the equipment under test from the HT-5000P until the front panel meter reads zero volts.

Using the HT-5000P Dielectric Withstand Tester

The dielectric withstand test involves high voltage and caution should be exercised when using the tester. The tester's return lead is connected to ground potential and when properly connected to the equipment being tested, it will guard against the operator contacting high voltage. Always make sure the test return lead is firmly connected to exposed dead metal. In the sections below, the tests are discussed.

Leakage Test

The HT-5000P leakage test uses a separate low-frequency circuit to check for excessive leakage between primary power components and ground. There is not a specific leakage current level pass/fail requirement at this time for most equipment, however, higher than normal leakage current on a particular part may indicate an assembly or component problem in the primary circuit.

The leakage current is also monitored by the HT-5000P to ensure that excessive leakage does not keep the tester from developing full voltage required for the high voltage test. The HT-5000P will provide full voltage at any leakage current level up to 10 mA AC or 5mA DC. The leakage current trip level is adjustable on the rear panel.

The leakage test is conducted by shorting the power and neutral conductors of the power supply cord and applying high voltage between them and the exposed dead metal of the chassis of the equipment being tested.

Excessive leakage current is not grounds for failure of the dielectric withstand test. Leakage current is a normal result of capacitance in the primary circuit between neutral or line conductors and ground. (In dielectric tests of some larger electric motors, leakage currents of as high as 95 mA are

considered acceptable by safety agencies.) However, leakage currents higher than normally anticipated for a particular model should not be ignored. This indicates problems of low resistance up to a short circuit between line/neutral and ground, and failures should be investigated. Failure modes are discussed below.

If the green **Full Voltage** LED lights and the test continues, the leakage current was below the amount set by the rear panel adjustment.

Sporadic Leakage Current Failures

If the red **Excess Leakage** LED lights, the buzzer sounds, and the test is terminated, the leakage current delivered to the equipment being tested was over the amount set by the rear panel adjustment. If other equipment of the same type routinely passes this test, there may be a problem with the primary circuit of the example being tested. The unit should be checked and reworked if necessary.

Chronic Leakage Current Failures

AC Dielectric Withstand testing charges all primary circuit capacitors connected line to ground or neutral to ground. The current flowing through these capacitors is defined as leakage current. If almost all examples of a model of equipment are not passing the leakage current test, we recommend that the leakage current limit be increased by resetting the leakage current level on the rear panel to a higher level.

If the leakage current adjustment of the HT-5000P is set to 10 mA AC and almost all examples of the model being tested are still failing, the primary circuit capacitance of the equipment may be too high to allow the AC dielectric withstand test to be used. This is due to the AC voltage charging all capacitors connected between primary voltage and ground. If the overall value of these capacitors causes a leakage current of more than 10 mA to flow at the desired test voltage, the HT-5000P cannot generate full voltage, and cannot successfully conduct the AC dielectric withstand test.

However, a DC dielectric withstand test is acceptable for most categories of equipment and will not charge the primary circuit capacitors. The DC test can be conducted by switching the front panel switch to DC. If the problem was due to high leakage current, the test should now be successful.

High Voltage Dielectric Withstand Test

This test checks for insulation system breakdowns between the primary and ground circuits. The HT-5000P uses a separate high-frequency transformer circuit to check for and detect arc breakdowns.

The dielectric withstand test is conducted by shorting the line and neutral conductors of the power supply cord and applying high voltage between them and the exposed dead metal of the chassis of the equipment being tested. The duration of the test is controlled by the test time control on the back panel. The test time is counted from the time the **Full Voltage** LED is lit to the completion of the test.

If the green **Hipot Pass** LED lights, the test cycle has been successfully completed. The equipment under the test is in accordance with the preset test parameters. The HT-5000P is ready to test the next piece of equipment.

High Voltage Dielectric Withstand Test Failures

If the red **Hipot Fail** LED lights, a problem has been found with the insulation system between primary and ground. The equipment under the test should be examined, reworked and successfully tested before being shipped.

High Voltage Discharge

The HT-5000P is designed to discharge the high voltage after completion of the dielectric withstand test. The equipment being tested should remain connected to the HT-5000P until the voltage has discharged to a safe level to protect the operator and to ensure that there is no energy stored in the tested equipment.

Section 2

Introduction and Specifications

This manual contains complete operating, maintenance and calibration instructions for the Compliance West USA Model HT-5000P Dielectric Withstand Tester.

The instrument is a bench-type Dielectric Withstand Tester with AC or DC Output, designed for laboratory testing of components and insulation systems.

The HT-5000P features automatic one button operation, with numerous safety features designed to protect the operator:

- The test return lead is directly connected to ground potential for operator safety.
- In case of trouble, the test can be immediately terminated at any time by pressing the red **RESET** button.
- Before the test can commence, the unit must be armed by pressing the red **RESET** Button. The test will not begin until the yellow **TEST** Button is pushed.
- If a failure is encountered, the high voltage is immediately shut down, a buzzer sounds, and any voltage stored in the equipment being tested is bled off by a resistor bank in the HT-5000P. The voltage discharge progress is shown by the front panel meter.
- Failure modes are shown by the front panel LED's for quick troubleshooting.

Convenience and testing features include:

- Voltage ramp, test time and leakage limit are adjustable.
- Voltage ramp and test duration timer are defeatable for specialized testing.
- Testing is terminated when breakdown is detected unless the breakdown detect switch is defeated.
- Test results are determined quickly, without operator intervention.
- Operator instructions are printed on the rear panel for quick reference.
- The HT-5000P V2 allows custom setups for voltage ramp, test time and leakage limit.
- Voltage is discharged by a resistor bank within the tester upon test completion. Discharge progress is shown on the front panel meter.

Your Tester is warranted for a period of one year upon shipment of the instrument to the original purchaser.

Specifications

Specifications for the HT-5000P V2 are listed in Table 1.

TESTING CIRCUITRY

Test Type:	AC & DC.
Max. Output Voltage:	5,000Vac / 6,000Vdc.
Leakage Current:	10mAac & 5mAdc.
Breakdown Detect:	Independent High Frequency Circuit (50KHz–500KHz).
Transformer Power:	<500VA.
Leakage Current Detect:	Independent Low Frequency Circuit.
Ramp Time Range:	1-5 Seconds.
Test Time Range:	1-60 Seconds.
Display:	4 Digits LED Display.
Voltage Meter Accuracy:	±2% from 500-5,000Vac / ±2% from 500-6,000Vdc.
Leakage Accuracy:	±0.1mA full scale.
Duty Cycle:	100%; Continuous.

ELECTRICAL

Rated Input Voltage:	120Vac. 220,230V optional
Frequency:	50/60Hz.
Fuse:	2A, 250V, time delay, 5x20mm.

SAFETY

Safety Interlock:	2-pin terminal block on rear panel; shorted for operation. (Optional)
Output Voltage Indicator:	Front panel meter directly connected to High Voltage.
Failure Indicator:	Visual; provided by red LED's, Audible; provided by buzzer. Test automatically terminated on failure.

OUTPUTS

HV:	High Voltage output.
RETURN:	4mm Socket (XEF-1RR), 1000V, CAT IV, 24A, Black.

ENVIRONMENTAL

Operating Temperature:	15-40°C.
Relative Humidity Range:	0-90% non-condensing.

GENERAL

Dimensions:	11.25" wide x 4.75" high x 13" deep.
Weight:	18lbs approx.
Product Package:	<ul style="list-style-type: none"> • HT-5000P V2 Tester. • HT-5000P V2 User Manual. • H.V Test lead. • Ground Test Lead with Crocodile Clip. • Power Cord. • NIST traceable calibration certificate to ANSI Z540. • Calibration Data Copy.

Table 1. HT-5000P V2 Specifications

Section 3

Operation

This section describes how to set up and make measurements with your tester. We recommend that you read the entire section carefully so that you can use all the features of your tester.

Setting up your Tester

Your tester is shipped in a special protective container that prevents damage to the instrument during shipping. Check the shipping order against the contents of the container and report any damage or short shipment to Compliance West USA.

If shipment of the instrument is necessary, please use the original shipping container. If the original shipping container is not available, be sure that adequate protection is provided to prevent damage during shipment. We recommend that the instrument be surrounded by at least three inches of shock-absorbing material on all sides of the container.

AC Line Voltage Requirements

AC line voltage requirements for your Tester are noted on the rear panel of the instrument. Do not connect the instrument to a different voltage source.

Fuse Replacement

There is a user-replaceable fuse (F1) located on the rear panel of the instrument. It is located behind a door in the Power Inlet-Power Switch-Fuse Holder device. The fuse rating is noted on the rear panel. Do not attempt to replace it with a fuse of any other rating.

Use the following procedure to replace the fuse F1:

1. Turn the power switch to the O or Off position.
2. Unplug the instrument from the source of supply.
3. Remove the power inlet cord from the instrument.
4. Using a small screwdriver, pry open the fuse holder door.
5. Replace the fuse with a new one with the same specifications.
6. Replace the fuse holder door and power inlet cord.

Front and Rear Panel Features

Before using your tester, take a few minutes to become familiar with the use of its controls, indicators, and connectors. The front panel features of the HT-5000P are shown in Figure 1 and described in Table 2. The rear panel features of the HT-5000P are shown in Figure 2 and described in Table 3.




Figure 1. Controls, Indicators, Connectors - Model HT-5000P Front Panel

ITEM	NAME	FUNCTION
1	Voltage adjust knob	Use to adjust the Output voltage.
2	RESET Button / Red Indicator	When lit, indicates that the HT-5000P is unarmed. This button must be pushed before the TEST Button is functional. When the RESET Button is pressed, the red RESET indicator goes out and the yellow TEST indicator is lit. PRESSING THE RESET BUTTON AT ANY TIME STOPS TEST.
3	TEST Button / Yellow Indicator	When lit, indicates that the HT-5000P is ready to test the connected equipment. The yellow TEST indicator goes out when the TEST Button is pressed.
4	Voltage Meter	Provides visual indication to the operator of the actual output voltage of the tester. Used to set the automatic voltage level during the setup procedure.
5	Ramp Bar Graph LED's	Individual LED's light in sequence from left to right as the test voltage ramps from zero to full voltage. LED's turn off at end of test.
6	AC/DC Switch	Selects AC or DC output. Changing switch setting does not change output until the next time the Reset button is pushed.
7	Full Voltage LED	If full voltage is successfully reached, the Full Voltage LED will light, and the high voltage duration timer starts.
8	Hipot Pass LED	At the end of the preset high voltage duration time, if no insulation breakdowns are encountered, the green light will light, and the test will terminate.
9	Hipot Fail LED	Indicates failure of high voltage test. If arcing or a flashover of the insulation system between primary parts and ground is encountered, the red breakdown LED will light, the internal buzzer will sound, and the test will be terminated.
10	Excess Leakage LED	Indicates failure of leakage current test. If leakage current between the primary circuit and ground is higher than the pre-set value, the red LED will light, the internal buzzer will sound, and the test will be terminated.
11	High Voltage Output Jack	High Voltage jack. For connection of high voltage test lead
12	Return Lead Receptacle	Grounded plug receptacle. The 18 AWG Test Return Lead provided is connected here.

Table 2. Controls, Indicators, Connectors - Model HT-5000P Front Panel




Figure 2. Controls, Indicators, Connectors - Model HT-5000P Rear Panel

ITEM	NAME	FUNCTION
13	Voltage Ramp Switch	When in ON position, high voltage ramp up time is as set by Ramp Time Adjustment, Item 14. When in DEFEAT position, high voltage is applied immediately.
14	Ramp Time Adjustment	Adjusts the amount of time used to reach the correct high voltage output level. See "Adjustment of the High Voltage Ramp Time" section.
15	Voltage Adjust	Adjusts the High Voltage output. See "Adjustment of the High Voltage Level" section.
16	Test Time Adjustment	Adjusts the test duration. See "Adjustment of the High Voltage Test Duration" section.
17	Leakage Limit Adjustment	Adjusts the alarm level for the excessive leakage current test. See "Adjustment of the Leakage Current Level" section.
18	Test Timer Switch	When in ON position, test duration is as set by Test Time Adjustment, Item 15. When in DEFEAT position, test continues as long as TEST Button on front panel is pressed. Minimum test time is approximately one second.
19	Failure Shutdown Switch	When in ON position, a leakage will terminate the test, dielectric failures will turn on the hipot fail light but will continue the test. When in DEFEAT position, test will continue.
20	Appliance Inlet / Fuse holder / Power Switch	AC Input. Replace line fuse. Turn Tester ON/OFF.
21	Fuse replacement warning / Rating of supply	Specifies replacement fuse and supply voltage used.
22	Directions	Information on how to use the tester.

Table 3. Controls, Indicators, Connectors - Model HT-5000P Rear Panel

Factory Settings

The unit is configured as shown when shipped from Compliance West USA:

Voltage Type:	AC.
Leakage Current Level:	1 mA.
Ramp Time:	1 second.
Output Voltage:	At minimum
Test Time:	1 second.

Adjustments of the various settings are shown below.

NOTE: The settings adjustments are to set the testing parameters, and do not take the place of the annual calibration required by the safety agencies

CAUTION

High voltage is generated by the HT-5000P V2 tester. Although the chassis of the equipment under test is grounded by the HT-5000P V2, a risk of shock exists, exercise safety precautions when operating the tester.

Display of Leakage Limit and Duration settings

To verify the Test Duration and Leakage Limit current settings, hold down the **RESET** button for 2 seconds. The meter will display “L” with the Leakage Limit value in mA. Hold down the **RESET** button again for 2 seconds and the meter will display “d” with the Test Duration set time in seconds.

Leakage Current Level Adjustment

1. AC Leakage Current can be set from 1.0 to 10.0 mA. DC Leakage Current can be set from 1.0 to 5.0 mA. To set the leakage limit follow the steps below.
2. Connect the HT-5000P to a correctly rated source of supply and turn the power switch to the I or ON position. Push the **RESET** button. The yellow **TEST** indicator should light, indicating that the HT-5000P is ready to test.
3. Use the AC/DC button to select the type of output voltage.
4. On the rear panel turn the **Leakage Limit** potentiometer. As soon as the potentiometer starts turning, the meter will start blinking, display “L”, and the value can be set in 0.1 mA increments from 1.0 to 10.0 mA AC or 1.0 to 5.0 mA DC depending on which mode you are in, AC or DC.
5. If tamperproof settings are desired, the **Leakage Limit** control shaft may be pulled away with a slight tug. (It may be reinserted for future adjustments.)

High Voltage Ramp Time Adjustment

This procedure controls the amount of time used to ramp the high voltage to the required level. The factory setting of 1 second is adequate for most situations. Use this procedure if adjustment to a different ramp time within the range of <1-5 seconds is required.

1. Connect the HT-5000P to a correctly rated source of supply and turn the power switch to the I or ON position. Push the **RESET** button. The yellow **TEST** indicator should light, indicating that the HT-5000P is ready to test.
2. Make sure there are no test leads connected to the HT-5000P. Push the **TEST** button.

3. When the **TEST** button is pressed, the voltage will ramp and hold. Adjust the **Ramp Time** control on the rear panel until the desired ramp time is reached. The test can be terminated at any time by pressing the **RESET** button.
4. If tamperproof settings are desired, the **Ramp Time** control shaft may be pulled away with a slight tug. (It may be reinserted for future adjustments.)

Adjustment of the High Voltage Level

This procedure controls the high voltage level used in the dielectric withstand test.

1. Adjust the Test Time control to approximately the middle of its travel.
2. Connect the HT-5000P to a correctly rated source of supply and turn the power switch to the I or ON position. Push the **RESET** button. The yellow **TEST** indicator should light, indicating that the HT-5000P is ready to test.
3. Use the AC/DC button to select the type of output voltage.
4. Make sure there are no test leads connected to the Tester. Push the **TEST** button.
5. After the **TEST** button is pressed, the voltage will ramp and hold. Set the **Voltage Adjust** control on the rear panel to the desired voltage.
6. Reset the test time using the procedure **Adjustment of the High Voltage Test Time**.

Adjustment of the High Voltage Test Time

This procedure sets the length of time the HT-5000P will conduct the high voltage test.

1. Connect the HT-5000P to a correctly rated source of supply and turn the power switch to the I or ON position. Push the **RESET** button. The yellow **TEST** indicator should light, indicating that the HT-5000P is ready to test.
2. On the rear panel turn the **Test Time** potentiometer. As soon as the potentiometer starts turning, the meter will display “d” and the value can be set in 1second increments from 1 to 60 seconds.
3. If tamperproof settings are desired, the **Leakage Limit** control shaft may be pulled away with a slight tug. (It may be reinserted for future adjustments.)

Setting the Rear Panel Switches

The table 4 represents the rear panel switches position use this table in conjunction with table 5 to define the desired operation of the HT-5000P.

Voltage Ramp	ON	DEFEAT	ON	DEFEAT	DEFEAT
Test Timer	ON	ON	DEFEAT	DEFEAT	DEFEAT
Failure Shutdown	ON	ON	ON	ON	DEFEAT
Condition	A	B	C	D	E

Table 4. Rear Panel Switch Truth Table.

A	Fully automatic operation. When Test button is pressed, the output voltage will ramp at a rate determined by the position of the TEST TIME adjustment knob. Test will stop automatically on all leakage or breakdown failures.
B	Voltage Ramp is defeated. Same as (A) above except that full voltage is produced at the output immediately. Test will stop automatically on all leakage or breakdown failures. For safety, we recommend that you begin testing with the front panel voltage knob set at minimum.
C	Test Timer is defeated. Same as (A) above except that after full voltage is reached, the test will continue only as long as the Test button is held in, minimum one second. Test will stop automatically on all leakage or breakdown failures.
D	Voltage Ramp and Test Timer are defeated. Full voltage is produced at the output immediately when the Test button is pressed. The test will continue only as long as the Test button is held in, minimum one second. Test will stop automatically on all leakage or breakdown failures. For safety, we recommend that you begin testing with the front panel voltage knob set at minimum.
E	Total Defeat. Full voltage is produced at the output immediately. Test will continue only as long as the TEST button is held in. The HT-5000P will not shut down on a leakage or dielectric failure, but the front panel Excess Leakage or Hipot Fail lights will indicate a failure. The Hipot Pass light will not light at the completion of a successful test. For safety, we recommend that you begin testing with the front panel voltage knob set at minimum. WARNING: Testing with the shutdown defeated is extremely hazardous. The HT-5000P can generate lethal levels of voltage and current. Therefore, care should be taken when examining the equipment being tested to locate areas of failure while the HT-5000P is operating. Do not operate the HT-5000P for extended periods under conditions of excess leakage or dielectric breakdown, as overheating and/or damage to the equipment being tested may result.
NOTE	All undefined states will defeat HT-5000P operation. Buzzer will sound.

Table 5. Rear Panel Switch Condition Table.

Operating Techniques

The following paragraphs describe how to operate your HT-5000P Dielectric Withstand Tester.

CAUTION:

High voltage is generated by the HT-5000P V2 tester. Although the chassis of the equipment under test is grounded by the HT-5000P V2, a risk of shock exists, exercise safety precautions when operating the tester.

Operational Test

The following procedure will verify that the HT-5000P is working correctly. We recommend that this procedure be conducted periodically to ensure proper operation of the tester.

CAUTION

High voltage (up to 5000 Volts AC and 6000 Volts DC) generated by the HT-5000P V2 is exposed during this test. The risk of shock exists. Exercise care when using the HT-5000P V2.

1. Turn the Tester on using the AC Power switch.
2. Set the Voltage Ramp switch, Test Timer switch, and Failure Shutdown switch to ON position.
3. Disconnect leads from the Output and Return jacks.
4. Set the Test Time to 15 seconds.
5. Push the RESET button. The TEST button should light.
6. Push the TEST button.
7. The HT-5000P tester will conduct a test. The meter will read a voltage, hold, and return to zero. During the test, the voltage can be adjusted using the Voltage Adjustment knob. At the end of the test, the Full Voltage, Hipot Pass, and RESET switch indicators should be lit.
8. Connect the red lead to the Output receptacle, and the black lead to the Return receptacle.
9. Connect the two leads together to simulate a high leakage current condition. Push the RESET button and then push the TEST button.
10. Test should terminate immediately and the buzzer should sound. The Excess Leakage Indicator and RESET button indicators should be lit. If a spark occurred, the Hipot Fail indicator will also be lit.
11. Leaving the red and black leads connected, disconnect the red lead from the HT-5000P.
12. Enable the voltage output by pressing the RESET button, then the TEST button. When the full voltage indicator lights, adjust the Voltage knob so the output is approx. 1500 volts. Press the RESET button to disable high voltage output.
13. Verify that the red and black leads are connected, the black lead is connected to the Return receptacle, and the red lead is disconnected from the HT-5000P.
14. **(This test simulates a dielectric breakdown. High voltage could exist on the alligator clips. Exercise caution to avoid shock.)** Push the RESET button, then the TEST button. After the full voltage indicator lights, pick up the red lead and insert it into the HV Output. The test will immediately terminate with a buzzer. The Full Voltage, Hipot Fail, and RESET button indicators should be lit.
15. Adjust the voltage and time to the desired settings

Passage of these tests indicates that the HT-5000P is functioning properly and that it is safe to use. If the results of the performance test are not in accordance with the above, service is required. Remove the HT-5000P from service and contact Compliance West USA, Inc. for servicing information.

Testing

This section describes how the HT-5000P is used to conduct a hipot test. Before continuing, we recommend that you read Section 1, "An Introduction to Dielectric Withstand Testing with the HT-5000P". It contains valuable safety, operation, and test result evaluation information which can help you conduct the test safely and correctly. The test can be stopped immediately at any time by pressing the red **RESET** button on the front panel.

Test Procedure Example:

1. Connect the HT-5000P to a correctly rated source of supply and turn the power switch to the I or ON position. Push the **RESET** button. The yellow **TEST** indicator should light, indicating that the HT-5000P is ready to test.
2. Plug the black return lead into the **Return** receptacle on the front panel of the HT-5000P.
3. Plug the red high voltage lead into the **Output** receptacle on the front panel of the HT-5000P.
4. Connect the return lead clip to an exposed metal part on the chassis of the device under test.
5. Connect the red lead clip to the current carrying conductors of the DUT and make sure the power switch on the equipment being tested is in the 1 or ON position (if applicable).
6. Push the **TEST** button. The HT-5000P V2 will:
 - a. Ramp the voltage at the rate set by the Ramp Time procedure.
 - If leakage current between the AC pins of the power supply cord (or point attached to the high voltage lead) and the chassis ground of the unit rises above the value set by the Leakage Limit procedure, the red **Excess Leakage** LED will light, the buzzer will sound, and the test will terminate.
 - If the leakage current level is below the set level when the high voltage set by the High Voltage Level procedure is reached, the green **Full Voltage** LED will light, and the test will continue.
 - b. Conduct the high voltage test for the time set in the Test Duration procedure.
 - If a breakdown of the insulation system between primary voltage and ground is detected, the red **Hipot Fail** LED will light, the buzzer will sound, and the test will terminate.
 - If no breakdown is detected, the high voltage will be bled off, the green **Hipot Pass** LED will light, and the red **RESET** switch will light.
7. For safety, the operator should not disconnect the cords until the **Hipot Pass** LED is lit and the reading on the front panel voltage meter has dropped to zero. This will ensure that the test voltage has been bled off.
8. The operator can now remove the equipment from the HT-5000P and connect another. The HT-5000P should then be armed by pressing the red **RESET** button. When ready, the operator then presses the yellow **TEST** button, and the test procedure will be conducted again.




Figure 3. Connection example

Test results

Hipot Pass: If the green **Hipot Pass** LED is lit, the equipment being tested passed all test parameters.

Red LED/Buzzer: Any red LED/buzzer test result means the equipment being tested failed a test phase. The equipment should be set aside, reworked and retested with acceptable results before it is shipped. General interpretations of test failures are included in Section 1, "Using the HT-5000P V2 Dielectric Withstand Tester".

Section 4

Technical Assistance

Technical Assistance from Compliance West USA is available:

Phone: (800) 748-6224

Hours: 8:00 AM - 4:00 PM Pacific Time.

Also available on our web site at: **www.compwest.com**

Contact:

Compliance West USA
650 Gateway Center Way, Suite D
San Diego, CA., 92102
United States of America.

Phone: (619) 878-9696

FAX: (619) 794-0404

Section 5

Maintenance and Calibration

WARNING

THESE SERVICE INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID ELECTRIC SHOCK, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN THE OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO.

Introduction

This section of the manual contains maintenance information for the HT-5000P Dielectric Withstand Tester. This maintenance information is divided into service information, general maintenance, a performance test, and a calibration procedure. The performance test is recommended as an acceptance test when the instrument is first received, and later as a preventative maintenance tool to verify proper instrument operation. A 1-year calibration cycle is recommended to maintain the specifications given in Section 1. The test equipment required for the calibration procedure is a DMM able to read true rms 0-5000 Vac \pm 1%, 0-6000 Vdc \pm 1%.

Service Information

The HT-5000P is warranted to the original purchaser for a period of 1 year. This warranty does not cover problems due to misuse or neglect.

Malfunctions which occur within the warranty period will be corrected at no charge, contact us prior to shipping to request a service ticket.

Compliance West USA offers calibration and repair services, contact us for more details on the cost. Ship the instrument and your remittance according to the instructions given by the manufacturer.

General Maintenance

Interior Access

NOTE

To avoid contaminating the PWB with oil from your fingers, handle it with the edges or wear gloves. If the PWB becomes contaminated, refer to the cleaning procedures given later in this section.

Calibration Access

Use the following procedures to gain access to the calibration adjustments of your instrument.

1. Set Line Power switch to OFF.
2. Disconnect the power cord from the rear of the instrument.
3. Remove the two upper screws on each side of the unit.
4. Grasp the top of the enclosure clamshell and lift it off the front and rear panels.
5. All calibration adjustments are now accessible.
6. To reassemble, reverse steps 1-5 above.

WARNING

Dangerous voltages exist when energized. Exercise extreme care when working on an energized circuit.

Cleaning

CAUTION

Do not use aromatic hydrocarbons or chlorinated solvents for cleaning. These solutions will react with the plastic materials used in the instrument.

Clean the front panel and case with a mild solution of detergent and a damp sponge. Clean dust from the PWB with clean, dry, low pressure (<20 psi).

Calibration Procedure

The Calibration Procedure should be performed annually and at any time your instrument has been repaired. The calibration procedure consists of two parts:

- 1) The Voltage Calibration adjustment calibrates the voltage output to agree with the meter reading.
- 2) The Current Calibration adjustment calibrates the current output used for the leakage limit.

NOTE

Allow the instrument to stabilize for approximately five minutes. Perform all calibration adjustments at an ambient temperature of 23 °C \pm 5 °C (73 °F \pm 9 °F).

WARNING

CALIBRATION ADJUSTMENTS ARE PERFORMED ON ENERGIZED CIRCUITS. EXERCISE CAUTION AT ALL TIMES, AND USE A NON-CONDUCTIVE TOOL FOR ALL ADJUSTMENTS.

Calibration and Software Version Information

This will allow the user to see the version of the software as well as who performed the last calibration.

1. Turn off the HT-5000P tester.
2. Hold in the **Reset** button while turning on the tester.
3. The meter will display 3 items:
 - A) The model number of the tester, 5000.
 - B) The version of the software
 - C) Laboratory number to designate who performed the last calibration:

Voltage Calibration Adjustment

Use the following procedure to calibrate the output voltage.

1. Ensure that all test leads are removed from the HT-5000P.
2. Turn OFF the HT-5000P tester.
3. To enter the **Calibration Mode** you MUST follow the following sequence:
 - Hold in both the **Test** and **Reset** buttons.
 - Turn on the HT-5000P tester.
 - Release the **Test** button, release the **Reset** button, press and hold the **Reset** button, press and hold the **Test** button, release the **Test** button, and then release the **Reset** button.
4. If the correct sequence was entered, the display will read "Sure", if not, start again at step 2 above.
5. While "Sure" is displayed on the screen you can:
 - A) Press **Reset** to exit out of the **Calibration Mode** and keep all the current values.
 - B) Press **Test** to enter the **Calibration Mode** and save new calibration values.
6. Once the **Calibration Mode** has been entered, the **Reset** button toggles between the 6 calibration menus: Volt, V1, V2, L1, L2, and bars. Make sure "V1" is displayed on the meter.
7. Hook up a calibrated 1000:1 voltage probe and a calibrated DMM between the Output receptacle and the Return jack on the front panel.
8. Use the AC/DC selector switch on the front panel to choose which voltage will be calibrated.
9. Turn the Voltage Adjust on the front panel to minimum (counterclockwise). Press the **Test** button and a voltage number will be displayed on the front panel meter (4500 for AC or 6000 for DC). Be careful as the HT-5000P will be putting out voltage at this point.
10. Turn the Voltage Adjust on the rear panel clockwise until the output on the DMM equals the appropriate voltage (4500 volts AC or 6000 volts DC) and press the Test button. The display will now display "V1" again.
11. Press the **Reset** button until "V2" is displayed on the front panel meter.
12. Turn the Voltage Adjust on the front panel to a minimum (counterclockwise). Press the **Test** button and 500 will be displayed on the front panel meter (for either AC or DC). Be careful as the HT-5000P will be putting out voltage at this point.
13. Turn the Voltage Adjust on the rear panel clockwise until the output on the DMM equals the appropriate voltage (500 volts AC or DC) and press the Test button. The display will now display "V2" again. The voltage is now calibrated.
14. Turn Off the HT-5000P tester.
15. The voltage can be verified by turning on the HT-5000P, running a test, and using the 1000:1 voltage probe to check the meter at different voltages. If the voltages are not within +/- 2% at each voltage, the voltage calibration must be performed again starting at step 1 above.




Figure 4. Connection for Voltage Adjustment

Current Calibration Adjustment

1. You must be in **Calibration Mode** as in step 3 under the Voltage Calibration Adjustment above.
2. Use the AC/DC selector switch on the front panel to choose AC.
3. Turn the Voltage Adjust on the front panel to minimum (counterclockwise).
4. Connect the output of the HT-5000P through a 60K ohm, 100-watt high voltage resistor in series with a calibrated DMM capable of measuring 10.0mA AC and returning to the Return jack on the front panel of the HT-5000P.
5. In the calibration mode, hit the Reset button until "L1" is displayed on the front panel.
6. Once "L1" is displayed, press the Test button once and 8.0 will be displayed.
7. Slowly increase the variac watching the current flowing on the DMM. Adjust the variac until 8.0mA AC is displayed on the DMM and then press the Test button.
8. The display will show "hold".
9. Wait until the display returns to "L1".
10. Turn the Voltage Adjust on the rear panel to minimum (counterclockwise).
11. In the calibration mode, hit the Reset button until "L2" is displayed on the front panel.
12. Once "L2" is displayed, press the Test button once and 1.0 will be displayed.
13. Slowly increase the variac watching the current flowing on the DMM. Adjust the variac until 1.0mA AC is displayed on the DMM and then press the Test button.
14. The display will show "hold".
15. Wait until the display returns to "L2". At this point the AC leakage current is calibrated.
16. Use the AC/DC selector switch on the front panel to choose DC.
17. Connect the output of the HT-5000P through a 240K ohm, 100-watt high voltage resistor in series with a calibrated DMM capable of measuring 5.0mA DC and returning to the Return jack on the front panel of the HT-5000P.
18. In the calibration mode, hit the Reset button until "L1" is displayed on the front panel.
19. Once "L1" is displayed, press the Test button once and 5.0 will be displayed.
20. Slowly increase the variac watching the current flowing on the DMM. Adjust the variac until 5.0mA DC is displayed on the DMM and then press the Test button.
21. The display will show "hold".
22. Wait until the display returns to "L1".
23. Turn the Voltage Adjust on the rear panel to minimum (counterclockwise).
24. In the calibration mode, hit the Reset button until "L2" is displayed on the front panel.
25. Once "L2" is displayed, press the Test button once and 1.0 will be displayed.
26. Slowly increase the variac watching the current flowing on the DMM. Increase the variac until 1.0mA DC is displayed on the DMM and then press the Test button.
27. The display will show "hold".
28. Wait until the display returns to "L2". At this point the DC leakage current is calibrated.




Figure 5. Connection for Current Adjustment